

## Step-by-Step Installation Instruction

- 1) Install NV1Q Rotator Control Program.  
*During the installation of the PC software a folder will be added onto the desktop. This folder contains all the support documentation to setup and operate the NV1Q Rotator system as well as the Arduino software.*
- 2) If you do not choose the hardware option to interface with the DXLab logging software, download and install VSPE (Virtual Serial Port Emulator) from [www.eterlogic.com](http://www.eterlogic.com)  
Launch VSPE  
Click on [Devise | Create] select [Pair] (choose your COM ports; e.g. COM20 & COM21)




Figure 1 - VSPE, setup example.


- 3) Download Arduino IDE from the Arduino website: <https://www.arduino.cc/en/Main/Software>  
Install Arduino IDE on your computer.
  - Connect USB cable to Arduino
  - Select Arduino COM port (Check in Windows 'Devices Manager' which port has been assigned to the Arduino.)
  - Load the Arduino Software located in folder: 'NV1Q\_Rotator\_Control'.

**Note:** When you install the Arduino IDE, it also installs the required USB driver. If you are using an Arduino clone you might have to install a new driver. The driver "CH341SER" that you can find in this folder will most likely work.
- 4) Launch the Program (*Program will create three new INI-files. Ignore rotator error messages*)
- 5) Start with setting up and customizing the Rotator Control System.
- 6) [Azimuth], select Show, Hide, or Lock. (*'Lock' de-activates the mouse over the map display.*)
- 7) [SW Buttons], select Show or Hide. (*This is for the relay buttons.*)
  - SW1 to SW6 are interactive.
  - SW7 and SW8 are independent ON/OFF switches.

**Note:** If you are being asked in your logging software to choose your 'Rotator' you have to select "YAESU" even if you are using a different brand.

## Setup Instruction

### [Setup | ComPort]




**[Arduino Serial Port]** (Same port as used for loading Arduino software)

**Note:** If there is a problem with connecting to the COM port, close the 'NV1Q Rotator' program and start it again.

**[DXLab Virtual Serial Port]** Mark the 'Check Box' if you are using VSPE and select the port that you have assigned in VSPE.

### [Setup | Rotator]



### [Calibration]

Turn your antenna north to 0° if you use 180° as 0-position or south to 180° if you use 0° as 0-position. 0-position is where the rotator feedback is 0V.

Increase (>) or decrease (<) the value to calibrate the displayed azimuth reading to the physical direction of the antenna.



### [Offset]

The Offset is to compensate for any coasting after the rotator stops.

### [0V Heading]

Select whether your rotator uses 0° or 180° as 0-position. (0V)  
(Default Setting is 180° with overlap)

### [Rotator Brake]

Make a check mark here if your rotator requires manual break control.  
Set your 'On-Delay' and 'Off-delay'

### [Speed Control]

All the speed settings will be in percentage of your maximum rotator speed.

Run Speed – Rotator speed when turning to a pre-select position.

Stall Speed – The speed where the rotator decreases to a very low value before stopping completely.

Manual Speed – Rotator speed when using the manual push-buttons.

### [Speed Ramp]

Number of degrees where the rotator starts reducing run speed and ramps down to stall speed.

### [Reverse Direction Delay]

Time delay, where rotator will stop when set to go in reverse direction while in motion.

## Azimuth Display

The default location is centered on grid square “FN32”.

The following steps explain how to customize the display:


Use "Paint" or any imaging software:

- Select any desired image (JPEG)
- Crop image to a square size
- Resize the image to 433 X 433 (Pixels)
- Save the image to a folder



Import the image by going to the Setup menu:


Click on [Setup | Azimuth Display]



Click on [Image] A Dialog Box opens; go to the folder and select the new image.

Click on [Default] to reset the display to its default location (FN32)

Change Azimuth Needle Color.



Click on [Color] A Dialog Box opens; select the desired needle color.